KIRKLAND Signature

By Whirlpool CORPORATION

CABINET PARTS

For Model: SEDS800JQ1
(Designer White)

29"ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: SEDS800JQ1
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT3397618	Instructions, Installation
	LIT8318480	Guide, Use & Care
	LIT8528190	Label, Wiring Diagram
		Following May Be Purchased
		DO−IT−YOURSELF REPAIR MANUALS
	LIT677818	Dryer
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, 8−18 x 3/8
5	3396795	Cover, Block
6	342043	Screw, 10−32 x 3/8
7	3396805	Panel, Rear
8	692989	Dry Rack Bracket
10	3406107	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	3406839	Dry Rack
13	3357011	Screw, 10−16 x 1/2
14	692495	Spring, Door (2)
15	3394083	Clip, Front Panel (2)
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length Package of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)
18	8530603	Cabinet
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21	695620	Panel, Front
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
26	337189	Clip, Hinge (2)
27	694091	Screw, 8−18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
33	696144	Strike, Door
35	695737	Door, Rear
36	3393549	Door, Front
37	690270	Handle, Door
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)
40	697776	Screw, 10−32 x 5/8
41	3397659	Block, Terminal
51	238088	Hinge, Top (2)
53	3394332	Idler & Slide Assembly
56	8066065	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	3394341	Pulley, 60 Hz.
62	661654	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)
67	3390731	Seal, Door
68	3393008	Screw, 10−16 x 1/2

TOP AND CONSOLE PARTS

For Model: SEDS800JQ1
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: SEDS800JQ1
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console
2		Wire, Jumper
	3401684	(Black)
	3401694	(Tan)
3	693995	Screw, Hex Head
4	8274437	Cap, End (L.H.)
5	297535	Bumper, Lint Lid
6	388326	Screw, Console
7	694419	Buzzer, Mini
8	8274434	Cap, End (R.H.)
9	3399640	Switch, Temperature
10	349639	Screen, Lint
11	8283378	Cover, Lint Screen
12	3978605	Hinge, R.H.
	3978606	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	3400859	Screw, Grounding
15	3395683	Connector (Motor)
16	8271390	Top
17	3950759	Knob, Control (3)
18	3394427	Clip−Harness
19	3397695	Wire, Jumper (Guard On/Off)
20	3401144	Connector, (PTS Relay)
21	8299783	Timer, 60 Hz.
22	3405156	Switch, Finish Guard
29	3390646	Screw, Mounting (8−18 x 5/16)
30	357213	Nut, Push−In (2)
31	8299873	Harness, Wiring
32	3396030	Wire, Jumper (Temperature)
33	3397269	Connector (Timer)
34	3347243	Connector 6−Circuit
35	94614	Terminal
39	3398096	Switch, Push−To−Start
48	8283182	Timer Knob Assembly
50	3936144	Connector
53	8271418	Bracket, Control
54	3977920	Panel, Control

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
		ACCESSORY PARTS
	279948	Kit, Dryer Repair
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)

BULKHEAD PARTS

For Model: SEDS800JQ1
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: SEDS800JQ1
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	487909	Screw, 8−15 x 1/2
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal−Bias
9	3977393	Thermal, Cut−Off (Hi−Limit Thermostat Illus. No.15 Included)
10	694089	Wheel, Blower (Includes Illus. No. 22)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	3397566	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
16	3977373	Bracket, Drum Light
17	3403585	Element, Heater
18	8066086	Drum Hole Plug
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	489463	Screw, 8−18 x 5/8
21	3390647	Screw, 8−18 x 1/2
22	3394196	Seal, Blower
33	3406124	Bulb
34	3402841	Lens, Drum Light
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3403413	Bulkhead
49	3403634	Socket Assembly
62	692526	Ring, Bearing (2)
63	97787	Screw, 11−16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal